

## Quick start guide Weedmaster -M

Before you can start the machine, you have to check all the fluid levels, for example motor/pump oil, fuel and water.

- Connect water supply and open tap.
- Open fuel tap by pushing the knob.
- Close the choke by pulling the knob.
- Pull-off some high-pressure hose from the reel.
- Start the engine with disconnected spraying gun and open the choke gradually if possible.
- Let the water float until there is no more air in it.
- Stop the engine and connect the spraying gun.
- Start the machine again.
- Switch on the burner by turning the burner knob.
- Now you can start working.

You can adjust the water temperature by turning the knob on the STC temperature controller. To lower the temperature, turn the knob anti-clockwise. Pressure will rise and temperature will be reduced. If you want to increase the temperature, turn the knob clockwise. Pressure will be reduced and temperature will rise.

To stop the machine.

- Switch off the burner.
- Open the spraying gun for a while to allow the burner to cool down a little and prevent for burning injuries.
- Switch off the machine.
- Close the water supply.
- Close the fuel tap by pulling the knob.
- Open the spraying gun to release the rest pressure.
- Disconnect the spraying gun from the hose.
- Store away the spraying hose and reel.